


Video conference system in the large seminar room F6
usage scenarios

local presentation

USER MANUAL

- Turn on the beamer



- **Connect the clickshare dongle to the notebook**

The dongle is on top of the black case near the window, another dongle is in the case.

- insert the clickshare dongle into the notebook's USB or USB-C port and wait until the circle on the dongle stops flashing,

This process takes a few seconds, please be patient!

- any screen messages that may appear, especially installation prompts, can be ignored, nothing needs to be installed,

- as soon as the circle on the dongle lights up continuously: pressing the button, the image is transmitted to the projector.



At the end of the dongle there is an adapter from USB-C to USB, which can be plugged in or removed as required.

IMPORTANT!

At the end of the presentation, please put back the dongle and switch off the projector.